
701167

Mobile Amplifier


Getting to know the Amplifier





Using the Amplifier

This Mobile Amplifier can be used for any devices with 3.5mm audio output such as MP3, PSP, PDA, laptop, mobile phone etc. (Fig.1)

- You need to charge the Amplifier first by connecting to a PC using an USB cable, and slide POWER to OFF.(Fig.2) It takes 3-4 hours to get full charge.
- To use the Amplifier, simply connect it to the device and slide POWER to ON. (Fig.3)
- 3. When not in use, slide POWER to OFF.







Safety Information

- Do not connect the Amplifier to incompatible device to avoid possible damages.
- * Do not insert any metal objects into the Amplifier.
- Do not expose the system to excessive moisture, rain, sand, or heat sources.
- Do not open the cabinet, no user-serviceable parts inside, refer servicing to qualified personnel only.
- * Certain countries may regulate the disposal of the battery used to power this product. Please consult with your local authority.

Trouble shooting

- 1. No sound
 - (a) make sure the plug is securely in place.
- (b) make sure there is sound output from the device connected to.
- (c) make sure the Amplifier has battery power.
- 2. Sound stops suddenly
 - (a) make sure the battery has power.
- 3. Sound weakens or has noise
- (a) make sure the battery has sufficient power.

67-09-401